

Guide for Downloading DT-800 OS

May 13 / 98

Latest OS is 2.00 version (General release version) named "DT800OS.FRM".

Procedure in case the I/O box is used

1. Set I/O Box DIP SW to the following setting

1	2	3	4	5	6	7	8	9	10
ON	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF

2. Connect DT-887AX (9pin - 9pin cross) cable between I/O box and PC correctly.

3. Operation

< HT Side >

- a. Press <FNC> + <3> + <PW> key

The following message on LCD screen will appear.

OS Loader	V1.00
	115K-P
ENT:Execute	
CLR:Cancel	
PW :Power OFF	

- b. Press <ENT> key

The LCD screen message will change as below.

OS Loader	V1.00
	115K-P
Refreshing ***	

(The LED lamp will be red and flashing for several seconds.)

OS Loader	V1.00
	115K-P
(IR)	
Check Link	

(The LED lamp will be green and ready to download OS from the PC.)

< PC Side >

Use "LDPC.EXE" utility

- c. Press the following command in DOS mode in your PC.

C:¥LDPC /B115200 dt800os.frm <RET>

- d. Then DT-800 will start to download OS from PC.

Procedure of case of using HT's

1. Use IR communication without cable
2. Place HTs like the following picture.



< Master HT >

< Target HT >

3. Target HT (Receive Side) Operation

- a. Press <FNC> + <3> + <PW> key

The following message on LCD screen will be appeared.

```
OS Loader      V1.00
                115K-P
ENT:Execute
CLR:Cancel
PW :Power OFF
```

- b. Press <ENT> key

The LCD screen message will change as below.

```
OS Loader      V1.00
                115K-P

Refreshing ***
```

(The LED lamp will be red and flashing for several seconds.)

```
OS Loader      V1.00
                115K-P

( IR )
Check Link
```

(The LED lamp will be green and ready to receive OS.)

4. Master HT (Send Side) Operation

c. Press <FNC> + <1> + <PW> key

The following message on LCD screen will be appeared.

```
Dump (OS)      V1.00
ENT:Execute
CLR:Cancel
PW :Power OFF
```

d. Press <ENT> key

```
Dump (OS)      V1.00
ENT:Execute
CLR:Cancel
PW :Power OFF
```

e. Then the master DT-800 starts to send OS to the target HT.

```
Dump (OS)      V1.00
                115.2kbps
( IR)
OS Ver 1.01
Sending ***.....
```